



DASCOM Americas

34 Lakeview Drive
Verona, Virginia 24482
(877) 434 1377

Installing the Cleaning Roller in the DC-2300 Card Printer

One Cleaning Roller is shipped with each Color Ribbon Cartridge in a package.


IMPORTANT: To provide optimum Print Quality when printing with the DC-2300, it is recommended that the cleaning roller is replaced each time you change the Color Ribbon. This is to guarantee the print quality and protect the print head.

Loading the Cleaning Roller


- 1) Obtain the Cleaning Roller from its package.
- 2) Start peeling the protection cover off the Cleaning Roller.



Location of where to place the Cleaning Roller in the Printer




3) Under the White Protective Cover is where to place the Cleaning Roller.



4) Push the Protective Cover towards the front of the Printer and drop the Cleaning Roller into its slots then peeling the Film off the Roller.



Cleaning Roller installed



The Printer is now ready for the Color Ribbon Cartridge installation then ready to use.