

Installing the Color Ribbon Cartridge in the DC-2300 Card Printer


IMPORTANT: To provide optimum Print Quality when printing with the DC-2300, it is recommended that the cleaning roller is replaced each time you change the Color Ribbon. This is to guarantee the print quality and protect the print head.

Loading the Color Ribbon Cartridge

- 1) Obtain the Color Ribbon Cartridge from the box and its plastic package.



- 2) Cartridge Loading Pins slots in the Printer



Location of Roller Pins



Ribbon Supply Roller Pin



Take Up Roller Pin

3) Drop in the Ribbon Cartridge into the Printer with the Take Up Roller end leading.



4) Finish installing, by fully dropping the Cartridge in place.

5) With the Cleaning Roller and the Color Ribbon Cartridge inserted, close the Top Cover.



The Printer is now ready for ready to use.