DASCOM Americas
34 Lakeview Drive
Verona, Virginia 24482
(877) 434 1377

Dascom DC-7600 White Paper

Proper Card Handling and Loading Recommendations

Cards used in the DC-7600 Printer should be free of contaminates. The Handling of the Cards should be to a minimum as possible and handling of the Cards edges is best. Oil or substance from your handling of the Cards can result in undesired Print Quality.
Always keep the Card in the manufacturers packing until used and use them as soon as possible to achieve the best Print Quality.

Improper handling of the Cards could result in –

1) Abnormal wear or damage to the Printer
2) Poor results in Print Quality

Remember, the results to Print Quality is best if the cards are handled by the edges rather than directly touching the surface of the Card. Oils from the skin can produce undesired outcome, particularly in white areas since the oil is heated during the printing process.

Please place the cards into the Printers Card Feeder Cassette carefully.

Ensure that the Magnetic Stripe CARDS and Contact Smart CARDS are properly placed in the card feeder (view drawing below).

If the card is inserted in the wrong direction, the code selection may not work properly.

DASCOM Americas
34 Lakeview Drive
Verona, Virginia 24482
(877) 434 1377

1) Open the slot cover backwards;

2) Move the card block lever to the left;

3) Press the lever handle with your hand and move the card to the left;

4) At the same time, insert the cards into the slot of the Cassette and release the lever handle from its holding position, returning the block by moving the lever to the right, to secure the cards.

5) Close the Cassette Top Cover.