Unboxing the DC-7600 Card Printer

To unbox the DC-7600 Card Printer safely, please follow this procedure –

1. Cut the Banding around the Box.

2. Cut the tape to open the Top of the Box.

3. Open the Box Top flaps, remove the accessories box.

4. Remove bottom Box Locking tabs, - pinch

5. Then pull the Lock tab out to remove.

6. With the Box Top opened, Accessories box removed, the bottom Box Locking tabs removed, grasp the Box Top Flaps and gently pull up to remove the Box from the Printer.
7. After the Printer is unboxed, remove any remaining inserts.
8. Remove the plastic bag surrounding the Printer
9. Using the Hand holds on the left and right side of the Printer, lift the Printer out of the container.

Remember to Bend Your Knees when lifting !

Scott Klemann – Sales / Applications Eng.
sklemann@dascom.com
(805) 279-7031

READ ME FIRST
DC-7600
Un-Boxing
Instructions