DASCOM
Americas
34 Lakeview Drive
Verona, Virginia 24482
(877) 434 1377

Firmware Update to DC-7600 In Windows 7

Proper Driver installation is needed before updating the DC-7600 Printer can begin, with the selection of the correct USB port or Ethernet connection established.

1) Click "Devices and Printers" in control panel

2) "Right click" on the Driver to select the "Printer Properties" of the DC-7600 Printer then click on the Preferences button.

3) At the DC-7600 Printing Preferences page, click on the Maintenance tab

4) Click on the Printer Settings button.

5) From the list of Parameter Items, select **Version Info** to verify what the current Firmware the Printer has.

6) Click on the Exit button and then OK to get back to the Printer Properties page to select the Utility tab.

7) Click on the Browse button to point what location the firmware to download to the Printer is and then select the Firmware (ie R600_v10.00.00.00 FWBTFPGA.mot)

8) After selecting the firmware path, click on “Update in ROOT mode”.

9) Turn off the printer. While pressing “Home” and “Set” buttons, hold them down while turning the power back On. Do not release the “Home” and “Set” button until the printer’s display shows “Update mode”.

10) The Driver will show screen showing the Firmware being transferred to the Printer followed up with a display shows success.

11) The display of the Printer will show progression of the Update.

12) Press EXIT button to back out of the Firmware Update Utility.

13) The Printer will continue to progress through the Update and when finished will power cycle, Off then On, coming up with a READY state.

You can verify that the Firmware has been updated by going to the GENERAL tab of the Printer Driver, selecting the Preferences button, select the Maintenance tab, Printer Settings button to select the VERSION INFO under the Parameter Items to then view the various Firmware levels, as outlined in steps 2, 3, 4 and 5 above.